



PARMCO

FS 600-LEG

If PART Number has N/A then Parmco is unable to supply.

Diag #	PART Number	DESCRIPTION
1	XPS30402600298	Trivet-Hob (L & R side) - FS600 - ALL MODELS
2	XPS30403000014	Large burner - Inner ring - FS600 - LEG, WHT, OBS
3	XPS30403000035	Large burner - Outer ring - FS600 - LEG, WHT, OBS
4	XPS30402900013	Burner body - Wok - FS600 - LEG, WHT, OBS
5	N/A - 2040500089	Upright oven panel assembly
6	N/A - 30313200045	Burner support
7	XPS30401800054	Thermocouple - WOK - FS600 - LEG, WHT, OBS
8	XPS30402800014	Burner Base - Wok - FS600 - LEG, WHT, OBS
9	XPS30402400027	Igniter candle - Wok - FS600 - LEG, WHT, OBS
10	N/A - 30300100021	Four holder
11	XPS30403100078	GAS VALVE LGE BURNER - FS 600
11.1	XPS30403100080	GAS VALVE MED BURNER - FS 600
11.2	XPS30403100094	GAS VALVE SML BURNER - FS 600
12	XPS30102100320	MICROSWITCH DAISY CHAIN - FS 600
13	N/A - 30401100001	Row chimneys
14	N/A - 30312600012	Cover board for duct
15	XPS30100700020	OVERHEAT THERMOSTAT 105deg, 20A - FS 600
16	N/A - 30301800020	Bottom board for duct
17	N/A - 30315000168	Panel for cavity
18	XPSPA2041000008	DOOR SEAL - FS 600, BKC, CER, GAS GAS, LEG, OBS, WHC, WHT
19	N/A - 2030300072	Embedded oven cavity
20	N/A - 30400300003	Fixing axies for side rack
21	XPS30101200070	Element - Lower - FS600 - ALL MODELS
22	N/A - 30301200004	Electric heat pipe fixing plate
23	N/A - 30302500013	Liner left stent
24	N/A - 30302600018	Hinge left fixed plate
25	N/A - 30302300023	Surrounded board in warehouse
26	N/A - 30306900007	Feet fixed plate
27	N/A - 30102400177	Power cord
28	XPS30102600004	JUNCTION BOX - FS 600, FS 600-LEG
29	N/A - 30302300022	Shell left and right side panels
30	N/A - 30302500014	Liner around the stent
31	N/A - 30302600019	Hinge fixing plate
32	N/A - 30402300002	Air inlet
33	N/A - 30402200002	Intake elbow
34	N/A - 30200300012	Sealing ring
35	N/A - 30100300010	Circulating fan components
36	N/A - 30307700011	Back support for cavity
37	XPS30101000001	LIGHT & SOCKET ASSEMBLY - FS STOVES
38	N/A - 30302200072	Enclosure back board
39	N/A - 30302900025	Oven fixing plate
40	N/A - 30302900026	Oven fixing plate

41	N/A - 30313200026	Oven bracket
42	XPS30102300008	IGNITION PACK - FS 600, FS 600-LEG
43	N/A - 30301900003	Guard board for duct
44	XPS30100400002	COOLING FAN - FS STOVES
45	N/A - 30401900159	Inlet pipe
46	N/A - 30306800001	Inlet pipe holder
47	N/A - 30307600001	Holder
48	XPS30100800003	COOLING FAN THERMOSTAT, 45 deg - ALL FS STOVES
49	N/A - 30402000458	Aluminum tube
49.1	N/A - 30402000459	Aluminum tube
49.2	N/A - 30402000460	Aluminum tube
49.3	N/A - 30402000461	Aluminum tube
50	XPS30402800020	Burner base- Sml - FS600 - LEG, WHT, OBS
51	XPS30401800075	Thermocouple - Small - FS600 - LEG, WHT, OBS
52	XPS30402400017	Igniter candle - Small - FS600 - LEG, WHT, OBS
53	XPS30402800029	Burner base- Med - FS600 - LEG, WHT, OBS
54	XPS30402900022	Burner body -Sml - FS600 - LEG, WHT, OBS
55	XPS30403000061	Burner cap- Med - FS600 - LEG, WHT, OBS
56	XPS30402900033	Burner body - Med - FS600 - LEG, WHT, OBS
57	XPS30403000061	Burner cap- Med - FS600 - LEG, WHT, OBS
58	XPS30402600080	Wok Trivet - FS600 - LEG, WHT, OBS
59-70	XPS2040200072	COMPLETE DOOR - FS 600 all S/S models
59	N/A - 30303500003	Door bracket
60	N/A - 30500400085	Inner glass
61	N/A - 30500300019	Middle glass
62	N/A - 30400700006	handle
63	N/A - 30201300001	Handle fixed sleeve
64	N/A - 30201200003	Intermediate glass panel
65	N/A - 30303400013	Door frame left and right bracket
66	N/A - 30303400014	Door frame left and right bracket
67	N/A - 30500200018	Door panel glass
68	N/A - 30400600005	Hinge assembly
69	N/A - 30200900013	Inner glass fixing block
70	N/A - 30200900014	Inner glass fixing block
71	N/A - 30302900027	Program-controlled device fixed board
72	XPS30100200057	CLOCK - ALL FS STOVES
73	N/A - 30209800011	Electronic timer button
74	XPS30100900003	THERMOSTAT - FS 600
75	XPO30100500031	FUNCTION SWITCH - OV7-1-8, OV7-3-8, FS 600
76	N/A - 30306500005	Panel of fixed links
77	XPS30102500003	INDICATOR LIGHT - FS STOVES
78	XPS30402500071	KNOB, PLASTIC - FS STOVES
79	N/A - 30305900078	Timer buttons
80	XPS30101200047	Element -Upper - FS600 - ALL MODELS
81	N/A - 30301100055	Back electric tube baffle
82	XPS30101200069	ELEMENT, CIRCULAR TRICYCLIC - FS 600 STOVES
83	N/A - 30400800002	Grilling rack handle
84	XPS30400200002	SIDE RACK LEFT - FS 600 STOVES
85	XPS30400200003	SIDE RACK RIGHT - FS 600 STOVES
86	XPS30304200002	BAKING TRAY - FS600

87	XPS30400100011	Wire rack - FS600 - ALL MODELS
88	N/A - 30304100001	Temperature control probe clip
89	N/A - 30309600031	Lower cover
90	N/A - 30313300015	Oven fixing bucket
91	N/A - 30202600002	Round adjust the feet
92	N/A - 30307900015	s.s frame for large oven
93	N/A - 30307900018	s.s frame for large oven
94	XPS30402100080	Jet - Lge - FS600 - LEG, WHT, OBS
94.1	XPS30402100077	Jet - Med - FS600 - LEG, WHT, OBS
94.2	XPS30402100031	Jet - Sml - FS600 - LEG, WHT, OBS
95	N/A - 30400200033	Side rack bracket
96	N/A - 30403800002	Iron chain
97	XPS30306200004	Rear panel
98	N/A - 30306300004	Rear panel cover
99	N/A - 30402200007	Intake elbow
100	N/A - 30404300002	Bushings
101	N/A - 30402300013	Pressure reducing valve