



PARMCO

FS 600-WHC

If PART Number is N/A then Parmco is unable to supply.

Diag #	PART Number	DESCRIPTION
1	N/A	OVEN DOOR TOP GASKET
2	N/A	OVEN DOOR SIDE GASKET
3	N/A	MIDDLE GLASS SUPPORT
4	N/A	HANDLE FIXING BOARD
5	N/A	DOOR FRAME SIDE SUPPORT PIECES
6	N/A	OVEN HANDLE
7	N/A	INNER GLASS
8	N/A	MIDDLE GLASS
9	N/A	OUTER GLASS
10	N/A	HINGE
11	N/A	INNER GLASS FIXER
12	N/A	INNER GLASS FIXER
13	N/A	OVEN DOOR TRIM
14	N/A	OVEN DOOR TRIM
15	N/A	OVEN SUPPORT BOARD
16	XPS30100200057	CLOCK - ALL FS STOVES
17	N/A	ENERY SWTICH
18	XPS30100900003	THERMOSTAT - FS 600
19	XPO30100500031	FUNCTION SWITCH - OV7-1-8, OV7-3-8, FS 600
20	N/A	DOOR FRAME FIXING BOARD
21	XPS30102500003	INDICATOR LIGHT - FS STOVES
22	XPS30402500071	KNOB, PLASTIC - FS STOVES
23	N/A	KNOB
24	XPS30101200047	Element -Upper - FS600 - ALL MODELS
25	N/A	ELEMENT
26	XPS30101200069	ELEMENT, CIRCULAR TRICYCLIC - FS 600 STOVES
27	XPS30400200003	SIDE RACK RIGHT - FS 600 STOVES
27	XPS30400200002	SIDE RACK LEFT - FS 600 STOVES
28	N/A	SIDE RACK WITH TELESCOPIC RUNNER
29	XPS30304200002	BAKING TRAY - FS600
30	XPS30400100011	Wire rack - FS600 - ALL MODELS
31	N/A	WIRE RACK
32	N/A	TIMER BUTTONS
33	N/A	COVER BOARD
34	N/A	RACK HANDLE
35	N/A	GLASS HOB
36	N/A	SS HOB PANEL TRIM
37	N/A	EGO ELEMENT,230V 1200W,Φ165
38	N/A	EGO ELEMENT,230V 2200W/1000W,Φ230
39	XPS30100800003	COOLING FAN THERMOSTAT, 45 deg - ALL FS STOVES
40	N/A	COOLING FAN THERMOSTAT
41	N/A	INDICATOR LIGHT

42	N/A	LIGHT HOLDER
43	N/A	AIR FLUE GUIDE
44	N/A	AIR FLUE COVER BOARD
45	N/A	OVERHEAT PROTECTOR
46	N/A	AIR FLUE BOTTOM BOARD
47	XPSA2041000008	DOOR SEAL - FS 600, BKC, CER, GAS GAS, LEG, OBS, WHC, WHT
48	N/A	DOOR SEAL
48	N/A	RACK PANEL
49	N/A	RACK PANEL
50	N/A	RACK SUPPORT PIN
51	N/A	CAPACITY ASSEMBLY
52	N/A	CAPACITY SUPPORT
53	XPS30101200070	Element - Lower - FS600 - ALL MODELS
54	N/A	BOTTOM ELEMENT
55	N/A	BOTTOM ELEMENT FIXING BOARD
56	N/A	COVER BOARD
57	N/A	FEET FIXING SUPPORT
58	N/A	FEET
59	N/A	FEET
60	N/A	SIDE PANEL
61	N/A	TELESCOPIC SUPPORT
62	N/A	BOTTOM COVER BOARD
63	N/A	DRAWER BOARD
64	N/A	DRAWER PANEL
65	N/A	TELESCOPIC RUNNER
66	N/A	TELESCOPIC FIXING
67	N/A	SPLESH BACK PANEL
68	N/A	HEATING ELEMENT 2000W/1100W,FISH
69	N/A	HEATING ELEMENT 230V,1800W,Φ200
70	N/A	ELEMENT FIXING BAORD
71	N/A	SCREW
72	N/A	SPRING
73	N/A	SCREW
74	N/A	SPRING WASHER
75	XPS30100400002	COOLING FAN - FS STOVES
76	N/A	SMOKE GUIDE
77	N/A	OVEN FIXING BOARD
78	N/A	OCVER BOARD
79	XPS30101000001	LIGHT & SOCKET ASSEMBLY - FS STOVES
80	N/A	CAPACITY SUPPORT BACK
81	XPS30100300024	Circulation Fan - FS600 - ALL MODELS
82	N/A	OVEN SUPPORTBOARD
83	N/A	OVEN FIXING BOARD
84	N/A	SIDE PANEL RIGHT
85	N/A	LINNER SIDE SUPPORT
86	N/A	NON-SKID FEET
87	N/A	HINGE FIXING BOARD
88	N/A	TEMPERATURE SENSOR FIXING
89	N/A	OVEN FIXING BOARD
90	N/A	KICK PANEL

91	N/A	OVEN FIXING BOARD
92	N/A	TERMINAL BOX
93	N/A	POWER CABLE