

PARMCO

FS600BC

If PART Number has N/A then it is only available as special order

Diag #	PART Number	DESCRIPTION
1	XX0040102257	SPLASH BACK UPSTAND
2	XX0041800752	CERAMIC COOKTOP
3	XX0040900960	OVAL DUAL ELEMENT
4	XX0040900462	LARGE ELEMENT
5	XX0040900961	LARGE DUAL ELEMENT
6	XX0040900463	SMALL ELEMENT
7	N/A - 0040102279	THE FURNACE PLATE FASTENER
8	XX0040102314	ELEMENT CLIP
9	N/A - 0040100534	THE FIXER OF THE LIGHT
10	XX0040900597A	HEAT INDICATOR LIGHT ASSEMBLY WITH CABLES
11	N/A - 0040900552A	FS FURNACE PLATE CABLE ASSEMBLY SHORT
12	N/A - 0040900552A	FS FURNACE PLATE CABLE ASSEMBLY SHORT
81	N/A - 0040900550A	FS FURNACE PLATE CABLE ASSEMBLY LONG
82	N/A - 0040900550A	FS FURNACE PLATE CABLE ASSEMBLY LONG
13	XX0040900830	FUNCTION SWITCH
14	XX0040900332	THERMOSTAT
15	XX0040900553	CLOCK
16	XX0040900106	DUAL SIMMERSTAT
17	XX0040900105	SINGLE SIMMERSTAT
18	N/A - 0040102178	SWITCH FIXING PLATE
19	N/A - 0040200424	INDICATOR SHIELD
20	XX0040900026A	ORANGE INDICATOR LIGHT
21	XX0040900025A	RED INDICATOR LIGHT
22	XX0041800660	DNO- CONTROL PANEL
23	XX0041300332	DNO - SILVER KNOBS
24	N/A - 0042100517	KICK-PLATE
25	N/A - 0042100519	FRONT COVER OF DRAWER (BLACK)
26	N/A - 0042100326	REAR COVER OF DRAWER (BLACK)
27	N/A - 0040102515	SELF - STARTER FASTENER
28	N/A - 0041300356	SELF CARTRIDGE ASSEMBLY
29	XX0042100325	COMPLETE DRAWER
30	N/A - 0040102194A	DRAWER BRACKET
31	N/A - 0040102194A	DRAWER BRACKET
32	XX0040200024	ADJUSTABLE FEET
33	N/A - 0042100500	LOWER BACK BEAM
34	N/A - 0042100096	60FR FRAME OF CAVITY
35	XX0041300220	TELESCOPIC RAIL FOR DRAWER
36	N/A - 0042100324	SIDE BEAM (RIGHT)
37	N/A - 0042100323	SIDE BEAM (LEFT)
38	XX0040101558	HINGE GUIDE
39	N/A - 0042100518	SIDE PANEL
40	N/A - 0042100081	CAVITY (BLACK ENAMEL)
41	N/A - 0040102181	REAR LEFT FIXER

PARMCO

FS600BC

If PART Number has N/A then it is only available as special order

Diag #	PART Number	DESCRIPTION
42	N/A - 0040102182	REAR RIGHT FIXER
43	N/A - 0042100500	LOWER BACK BEAM
44	XX0040101434	HEAT SINK PARTITION
45	N/A - 0040101433	TOP COVER OF COOLING FAN SYSTEM
46	XX0040900426	COOLING FAN
47	N/A - 0040102184	UPPER REAR CROSSPIECE
48	N/A - 0040101029	BACK COVER
49	XX0040900570	TERMINAL/CONNECTION/JUNCTION BOX
50	N/A - 0040901251	POWER LINE
51	XX0040101502	GRILL RACK
52	XX0042100360	OVEN TRAY
53	XX0040101503A	WIRE RACK
54	XX0040101017	SIDE RACK FIXING SCREWS
55	XX0041300227	SIDE RACK LEFT
56	XX0041300228	SIDE RACK RIGHT
57	XX0042100426	CATALYTIC LINERS
58	N/A - 0042100377	ISOLATION OF REAR FAN
59	XX0040900980	CIRCULAR ELEMENT
60	XX0040400161	DOOR SEAL
61	XX0040900029	LAMP/LIGHT ASSEMBLY
62	XX0040900484	GRILL ELEMENT
63	N/A - 0020101208	GAS BAKING BOTTOM PANEL
64	N/A - 0040101509	PROTECTIVE SHIELD OF LOWER HEATER
65	XX0040900031	LOWER ELEMENT
66	N/A - 0040901053A	OVEN WIRE
67	XX0040900467	CIRCULAR FAN MOTOR
68	N/A - 0040102183	THE FIXING PLATE OF REAR FAN
69	N/A - 0040700397	THE INSIDE DOOR GLASS
70	N/A - 0040700876	THE MIDDLE DOOR GLASS
71	XX0040200015	LOWER FIXER OF THE INSIDE DOOR GLASS(RIGHT)
72	XX0040200013	LOWER FIXER OF THE INSIDE DOOR GLASS(LEFT)
73	XX0040200019	UPPER FIXER OF THE INSIDE DOOR GLASS(RIGHT)
74	XX0040200017	UPPER FIXER OF THE INSIDE DOOR GLASS(LEFT)
75	N/A - 0040800288	THE FIXER OF THE MIDDLE DOOR GLASS
76	N/A - 0042100094	VENT HOLE OF DOOR
77	XX0041300321	HINGE
78	N/A - 0041800753	THE OUTSIDE DOOR GLASS ASSEMBLY
79	XX0041300235	DNO - DOOR HANDLE
80	N/A - 0040803345	DOOR ASSEMBLY
81	XX0040900240	COOLING FAN THERMOSTAT 65°
82	XX0040900638	OVERHEAT THERMOSTAT
83	N/A - 0040101591	FIXER OF TEMPERATURE LIMITER