

PARTCO

FS600SI

If PART Number has N/A then it is only available as special order

Diag #	PART Number	DESCRIPTION
1	N/A - 40803608	COOKTOP WITH CERAMIC GLASS (STAINLESS STEEL)
0	N/A - 0042300372	MICROCRYSTALLINE COOKTOP
0	N/A - 0040700800	DEVITRIFIED GLASS
2	N/A - 0070900627A	BIG HEATING ELEMENT
3	N/A - 0070900628A	SMALL HEATING ELEMENT
4	XX0070900199	THERMISTOR/SENSOR
5	N/A - 0070200048	PLASTIC SPACER
6	N/A - 0070900319	COOLING FAN
7	N/A - 0070900868	PCB OF HEATING ELEMENT
8	N/A - 0070900866	PCB OF COOKTOP
9	N/A - 0070900251	DISPLAY PCB OF COOKTOP
10	N/A - 0040200571	PLASTIC FIXER OF DISPLAY PCB
11	N/A - 0070200042	PLASTIC FIXER OF HEATING ELEMENT PCB
12	N/A - 0070200043	FIXER OF INDUCTION CONTROL PCB
13	N/A - 0040101667	COOKTOP BOTTOM SHELL
14	XX0040901258	WIRING FOR PCB
15	N/A - 0040900930	WIRE OF CONNECTION BOX-PCB COMTROL (RED)
16	N/A - 0040900931	WIRE OF CONNECTION BOX-PCB COMTROL (BRUE)
17	N/A - 0040900932	WIRE OF CONNECTION BOX-PCB COMTROL
18	N/A - 0040900950	WIRE OF HEATIN ELEMENT PCB-PCB COMTROL
19	N/A - 0040901272	WIRE OF HEATIN ELEMENT PCB--PCB COMTROL
20	XX0040102257	SPLASH BACK UPSTAND
21	N/A - 0040102853	SWITCH FIXING PLATE
22	N/A - 0040803609	FRONT PANEL
0	N/A - 0040102855	FRONT PANNEL
0	N/A - 0040701392	COMPUTER BOARD GLASS
0	N/A - 0040102102	PANEL SWITCH FIXED PLATE BRACKET
23	N/A - 0040901530A	THE POWER BOARD IS CONNECTED TO THE WIRING
24	XX0040901557	CONTROL THE COMPUTER BOARD
25	XX0040901413	CONTROL SWITCH
26	XX0040900570	TERMINAL/CONNECTION/JUNCTION BOX
27	XX0040900980	CIRCULAR ELEMENT
28	N/A - 0040102182	RIGHT REAR COLUMN
29	N/A - 0040101592	INNER LINER BACK STIFFENING PLATE
30	N/A - 0040102183	REAR FAN FIXING PLATE
31	N/A - 0040102181	LEFT POST
32	XX0040900029	LAMP/LIGHT ASSEMBLY
33	N/A - 0041300096A	ANTI-TIPPING CHAIN
34	XX0040900654	COOLING FAN
35	N/A - 0042100377	IMPELLER COVER
36	XX0040101434	HEAT SINK PARTITION
37	N/A - 0040101674	AIR OUTLET SHEET METAL
38	XX0040901579	CONTROL THE COMPUTER BOARD

PARTCO

FS600SI

If PART Number has N/A then it is only available as special order

Diag #	PART Number	DESCRIPTION
39	N/A - 0042100308	RACK TYPE INNER LINER
40	XX0040900638	OVERHEAT THERMOSTAT
41	XX0040900240	COOLING FAN THERMOSTAT 65°
42	N/A - 0040200571	PLASTIC SUPPORT SEAT FOR POWER BOARD
43	N/A - 0040100820	HANGER FIXED PIN
44	XX0040400161	DOOR SEAL
45	N/A - 0040102205	THE SUPPORT BEAM OF COOKTOP
46	N/A - 0040101433	54DFS COOLING SYSTEM ROOF
47	XX0040900484	GRILL ELEMENT
48	N/A - 0040102852	FIXING PIECE IN FRONT OF STOVE
49	XX0041300227	SIDE RACK LEFT
50	XX0041300228	SIDE RACK RIGHT
51	XX0040900343	TEMPERATURE SENSOR
52	XX0042100426	CATALYTIC LINERS
53	N/A - 0040102179	SIDE PLATE
54	N/A - 0040200288	TWISTED LOOP
55	N/A - 0042100096	BOX BODY FRAME
56	XX0040101558	HINGE GUIDE
57	N/A - 0040101698	LOWER LEFT COLUMN
58	N/A - 0040101699	LOWER RIGHT COLUMN
59	N/A - 0042100323	SIDE PLATE, BEAM-LEFT
60	N/A - 0040102192	DRAWER FRONT COVER
61	N/A - 0042100326	BACK COVER OF DRAWER
62	N/A - 0042100322	LOWER FRONT BEAM
63	N/A - 0042300306	KICK PROOF PLATE
64	XX0042100325	COMPLETE DRAWER
65	N/A - 0041300420	SLIDE RAIL
66	N/A - 0041300440	SLIDE RAIL
67	N/A - 0042100500	UNDER THE REAR BEAM
68	N/A - 0042100324	SIDE PLATE, BEAM-RIGHT
69	N/A - 0040101509	LOWER HEATER SHIELD
70	N/A - 0020101208	BOTTOM PARTITION OF LOWER HEATER
71	XX0040200024	ADJUSTABLE FEET
72	XX0040900031	LOWER ELEMENT
73	N/A - 0040901439	HARNESS ASSEMBLY
74	N/A - 0040901251	POWER CABLE
75	XX0042100360	OVEN TRAY
76	XX0040101502	GRILL RACK
77	XX0040101503A	WIRE RACK
78	N/A - 0040802006	BOX BODY GLASS COTTON
79	N/A - 0040802123	GLASS WOOL ON THE BACK
80	XX0040900467	CIRCULAR FAN MOTOR
81	N/A - 0040103027	BACK PLATE

PARTCO

FS600SI

If PART Number has N/A then it is only available as special order

Diag #	PART Number	DESCRIPTION
82	N/A - 0040803344	DOOR BODY ASSEMBLY
83	XX0041300235	DNO - DOOR HANDLE
84	N/A - 0041800541	EXTERIOR GLASS ASSEMBLY
0	N/A - 0042100093	DOOR BODY SIDE FIXER LEFT
0	N/A - 0042100092	DOOR BODY SIDE FIXER RIGHT
0	N/A - 0040700815	OUTSIDE GLASS
0	N/A - 0040102510	
0	N/A - 0040102511	
85	XX0041300321	HINGE
86	XX0040200013	LOWER FIXER OF THE INSIDE DOOR GLASS(LEFT)
87	XX0040200015	LOWER FIXER OF THE INSIDE DOOR GLASS(RIGHT)
88	N/A - 0040700876	MID-GLAZING
89	N/A - 0040800288	GLASS HOOK
90	N/A - 0042100094	AIR OUTLET OF DOOR BODY
91	N/A - 0040700397	GLASS INSIDE THE DOOR
92	XX0040200017	UPPER FIXER OF THE INSIDE DOOR GLASS(LEFT)
93	XX0040200019	UPPER FIXER OF THE INSIDE DOOR GLASS(RIGHT)