

PARMCO

FS60WP4

If PART Number has N/A then it is only available as special order

Diag #	PART Number	DESCRIPTION
1	N/A - 0040800486	SPLASHBACK
2	N/A - 0042100293	COOKTOP
3	XX0040900460	ELEMENT LARGE
4	XX0040900461	ELEMENT SMALL
5	N/A - 0020101188	FIXER OF BIG HOTPALTE
6	N/A - 0020101189	FIXER OF SMALL HOTPALTE
7	N/A - 0040801047	GROUNDING METAL
8	N/A - 0020100920	GROUNDING METAL
9	N/A - 0040900261A	FS FURNACE PLATE CABLE ASSEMBLY (LONG)
10	N/A - 0040900262A	FS FURNACE PLATE CABLE ASSEMBLY (SHORT)
11	XX0040900721	FUNCTION SWITCH
12	XX0040900332	THERMOSTAT
13	XX0040901391	MECHANICAL TIMER
14	XX0040900566	ELEMENT CONTROL SWITCH
15	XX0041800891	CONTROL PANEL
16	XX0040300483	KNOB BASE FUNCTION SWITCH
17	XX0040200693	THE SEAT OF TEMPERATURE CONTROL
18	XX0040200160	KNOB BASE TIMER
19	XX0040200149	KNOB BASE ELEMENT CONTROL SWITCH
20	XX0040100020	KNOB SPRING
21	XX0040900025A	INDICATOR RED
22	XX0040900026A	INDICATOR LIGHT ORANGE
23	XX0040200147	KNOB
24	XX0040200147	KNOB
25	N/A - 0041300096A	ANTI-OVERTURN CHAIN
26	N/A - 0040101029	BACK COVER
27	XX0040900570	TERMINAL BOX
28	XX0040900011	OVERHEAT THERMOSTAT
29	N/A - 0040100131	HEAT SHIELD OF TEMPERATURE LIMITER
30	N/A - 0040101185	LEFT BACK PILLAR
31	N/A - 0020101133	UPPER REAR CROSSPIECE
32	N/A - 0040801464	VENT-PIPE OF OVEN
33	N/A - 0040100027	SEAT OF VENT-PIPE
34	N/A - 0040101186	RIGHT BACK PILLAR
35	N/A - 0040800048	BACK GLASS COTTON
36	N/A - 0040800525	GLASS COTTON
37	N/A - 0042100587	CAVITY
38	XX0040900031	ELEMENT LOWER
39	N/A - 0020101216	SHIELD OF LOWER HEATER
40	N/A - 0020101208	BOTTOM PARTITION OF LOWER HEATER
41	N/A - 0042100422	FRAME ASSEMBLY
42	XX0040101646	TEMPERATURE SENSOR
43	XX0040400060	SEAL DOOR

P A R M C O

FS60WP4

If PART Number has N/A then it is only available as special order

Diag #	PART Number	DESCRIPTION
44	XX0040900029	LAMP/LIGHT ASSEMBLY
45	XX0040900030A	ELEMENT UPPER
46	N/A - 0040102961	FRONT MOUNTING PART OF COOKTOP
47	N/A - 0040801091	RIGHT SIDE PANNEL
48	N/A - 0040801087	LEFT SIDE PANNEL
49	N/A - 0040500004	OVERTURN CHECK
50	N/A - 0040801102	LOWER ANTERIOR CROSSPIECE (60FS)
51	N/A - 0040801284	LOWER ANTERIOR CROSSPIECE (60FS)
52	N/A - 0040200025	LIMITER OF DRAWER
53	N/A - 0020101212	SLIDEWAY OF DRAWER
54	N/A - 0040101071	THE BOTTOM FIXER OF RIGHT SIDE PANNEL
55	N/A - 0040101070	THE BOTTOM FIXER OF LEFT SIDE PANNEL
56	XX0040200024	ADJUSTABLE FEET
57	N/A - 0040900311A	OVEN WIRE
58	N/A - 0040200026	GUIDE OF DRAWER
59	XX0040800744	DRAWER INNER
60	XX0040800529	DRAWER COVER (WHITE)
61	N/A - 0040200179	DRAWER FRONT COVER HAND-CLASPING
62	XX0040100821A	WIRE RACK
63	XX0042100359	TRAY
64	XX0040100805	SIDE RACKS
65	XX0040100820	SIDE RACK FIXING SCREW
66	N/A - 0040700321	THE INSIDE DOOR GLASS
67	XX0041300040	HINGE
68	N/A - 0040700215	THE MIDDLE-LAYER GLASS
69	N/A - 0040800288	GLASS HOOK
70	XX0040200019	UPPER FIXER OF THE INSIDE DOOR GLASS(RIGHT)
71	XX0040200017	UPPER FIXER OF THE INSIDE DOOR GLASS(LEFT)
72	XX0040200015	LOWER FIXER OF THE INSIDE DOOR GLASS(RIGHT)
73	XX0040200013	LOWER FIXER OF THE INSIDE DOOR GLASS(LEFT)
74	N/A - 0010801929	VENTHOLE OF DOOR
75	N/A - 0040101025	H10 HANDLE
76	N/A - 0041800157	THE DOOR GLASS HAS BEEN SOILED SIDE OF THE FIXED PARTS OF THE DOOR
77	N/A - 0040803400	DOOR ASSEMBLY