

PARMCO

OV145B7

If PART Number has N/A then it is only available as special order

Diag #	PART Number	DESCRIPTION
1	N/A - 0042100765	CAVITY (ENAMELED BLACK)
2	XX0040900343	TEMPERATURE SENSOR
3	N/A - 0040803612	REAR ATTEMPERATOR
4	N/A - 0040103085	REAR SUPPORT
5	N/A - 0042300028	COOLING FAN SUPPORT
6	XX0040900467	CIRCULAR FAN MOTOR
7	N/A - 0040101592	THE BACK PLATE
8	XX0040900031	ELEMENT LOWER
9	N/A - 0020101216	ISOLATION OF LOWER HEATER
10	N/A - 0042100753	THE FRONT SUPPORT(RIGHT) (PAINTED MATT BLACK)
11	N/A - 0042100766	FRAME WATER GROOVE
12	N/A - 0042100754	FRAME OF CAVITY (PAINTED MATT BLACK)
13	N/A - 0042100752	THE FRONT SUPPORT(LEFT) (PAINTED MATT BLACK)
14	XX0040900980	CIRCULAR ELEMENT
15	XX0040900029	LAMP/LIGHT ASSEMBLY
16	XX40900406	ELEMENT UPPER
17	XX0040101558	HINGE GUIDE
18	N/A - 0040103082	TOP PANEL
19	XX0040900240	COOLING FAN THERMOSTAT 65°
20	XX0040900654	COOLING FAN
21	N/A - 0040103120	VENTILATION SIDE WASHER 2MM
22	N/A - 0040101508	BASE PLATE OF COOLING SYSTEM
23	N/A - 0040101674	AIR OUTLET
24	XX0040900011	OVERHEAT THERMOSTAT
25	N/A - 0020101231	MAIN OVEN FIXER OF TEMPERATURE LIMITER
26	N/A - 40801359	CAVITY ATTEMPERATOR
27	N/A - 0040101754	BACK COVER
28	XX0040900027	CONNECTOR/JUNCTION/TERMINAL BOX
29	XX0040900900	POWER LINE 1.5M
30	N/A - 0040200356	LIFT
31	N/A - 0040103084	RIGHT SIDE PANEL
32	N/A - 0040103091	BOTTOM PANEL
33	N/A - 0040103125	BOTTOM ISOLATION PLATE
34	XX0040800027	FAN ELEMENT COVER
35	XX40101337	SIDE RACK
36	XX0042100436	TRAY BLACK
37	XX0040101423	GRILL RACK
38	XX0040100821A	WIRE RACK
39	XX0040803613	COMPLETE OVEN DOOR 600MM
40	XX0040200384	INNER GLASS UPPER CLIP LEFT
41	N/A - 0040801712	VENT HOLE OF DOOR (PAINTED MATT BLACK)
42	XX0040200385	INNER GLASS UPPER CLIP RIGHT
43	N/A - 0040400078	UPPER FIXER OF THE MIDDLE DOOR GLASS

PARMCO

OV145B7

If PART Number has N/A then it is only available as special order

Diag #	PART Number	DESCRIPTION
44	N/A - 0040701558	THE INSIDE DOOR GLASS
45	N/A - 0040701584	THE MIDDLE DOOR GLASS
46	N/A - 0040200511	LOWER FIXER OF THE INSIDE DOOR GLASS(RIGHT)
47	N/A - 0040200510	LOWER FIXER OF THE INSIDE DOOR GLASS(LEFT)
48	XX0040100023	HINGES LEFT & RIGHT
49	N/A - 0041801024	DOOR GLASS ASSEMBLY
50	N/A - 0041300431	HANDLE
51	XX0040101010	KNOB
52	N/A - 0041801025	PANEL GLASS ASSEMBLY
53	N/A - 0040200431	COMPUTER BOARD FIXER
54	XX0040901163A	CLOCK
55	XX0040900025A	INDICATOR RED
56	N/A - 0042100427	FIXER OF CONTROL PANEL (PAINTED MATTE BLACK)
57	XX0040900828	FUNCTION SWITCH
58	XX0040900332	THERMOSTAT
59	XX40400064	SEAL
60	N/A - 0040103083	LEFT SIDE PANEL
61	N/A - 0040901625A	CONTROL CABLE ASSEMBLY
62	XX0040803509	DOOR SENSOR ASSEMBLY
63	N/A - 0040200704	DOOR SENSOR FRAME
64	N/A - 0040200705	DOOR SENSOR GUIDE
65	N/A - 0041300211	DOOR SENSOR SPRING
66	N/A - 0040901554	DOOR SENSOR
67	N/A - 0040101565	TOP PLATE OF COOLING SYSTEM