

PARMCO

OX-1-6S-5

If PART Number has N/A then it is only available as special order

Diag #	PART Number	DESCRIPTION
1	N/A - 0042100200	Frame of tube (Painted black)
2	N/A - 0040101962	The fixer of hinge
3	XXO0040100821	WIRE RACK - OX-1-6S-5 PPOV-6S-SIDE
4	N/A - 0040100108	Tray clamp
5	XXO0040101423	GRILL RACK - OX-1-6S-5 PPOV-6S-SIDE
6	XXO0040801418	ROAST DISH - OX-1-6S-5
7	XXO0040900244	ELEMENT, UPPER - OX-1-6S-8 PPOV-6S-SIDE, PPOV-6S-DT-3
8	XXO0040900029	COMPLETE LIGHT FITTING FS*00**
9	XXO0040101646	Temp Sensor - both ovens - PPOV-6S-DT-3
10	XXO0040802713	DOOR SEAL - OX-1-6S-5
11	N/A - 0040800027	Isolation of rear fan (Enameled black)
12	XXO0040900052	ELEMENT,CIRCULAR - OX ovens, DT ovens, Verso ovens
13	N/A - 0042100292	Cavity (Enameled black)
14	N/A - 0020101346	Rear support
15	N/A - 0040101970	Vent hole of oven
16	N/A - 0040101969	Ventilated plate
17	XXO0040900033	COOLING FAN - OX-1-6S-5 PPOV-6S-SIDE
18	XXO0040900011	OVERHEAT THERM 170 deg
19	N/A - 0040800525	Main cavity isolation
20	N/A - 0040802788	Rear isolation
21	XXO0040900780	CIRCULAR FAN MOTOR - OX-1-6S-5
22	N/A - 0042300106	Fixer of rear fan
23	XXO0040200443	KNOB - OX-1-6S-5
24	XXO0041800109	Glass control panel assembly (black) OX-1-6S-5
25	XXO0040900025	INDICATOR LIGHT - VERSO 1-1, OX-1-6S-5 OX7-2 OX7-3 OX7-4 OX7-5 PPOV-6S-SIDE
26	XXO0040900332	THERMOSTAT - VERSO 1-1, OX-1-6S-5 OX7-2 OX7-3 OX7-4 OX7-5 PPOV-6S-SIDE FS*00**
27	XXO0040900739	TIMER - OX-1-6-5, OX7-2-6S-5 OX7-3-6S-5 OX7-5-6S-5 OX7-4-6W-5
28	XXO0040900558	FUNCTION SWITCH - OX-1-6S-5, OX7-2-6S-5
29	N/A - 0040101965	Control panel fixed pieces (left)
30	N/A - 0040101966	Control panel fixed pieces (right)
31	N/A - 0040100820	The fixer of the rack
32	XXO0040100805	SIDE RACKS/ Main oven - OX-1-6S-5 PPOV-6S-SIDE, PPOV- DT-3/4
33	N/A - 0040900770	oven wire
34	XXO0040900031	ELEMENT, LOWER FS600**
35	N/A - 0020101216	Isolation of lower heater
36	N/A - 0040101958	Left side panel
37	N/A - 0040200356	Built-under double oven Side panel button hand
38	N/A - 0040101961	Top panel of BIE

39	N/A - 0040101968	Back cover of BIE
40	XXO0040900027	Terminal Box - OX7-3 OX7-4 OX7-5 PPOV-6S-SIDE FS*00*G
41	N/A - 0040900900	Power wire
42	N/A - 0040700531	Inside door glass
43	XXO0041300192	Hinge - OX-1-6S-8
44	XXO0040200369	Inner glass lower clip - left - OX7
45	XXO0040200370	Inner glass lower clip - right - OX7
46	N/A - 0040700624	The middle door glass
47	N/A - 0040800288	The fixer of the middle door glass
48	N/A - 0042100201	Vent hole of door (painted black)
49	N/A - 0041800110	Outside door glass assembly (SS)
50	N/A - 0040100464	H1 handle (SS)
51	XXO0040802840	DOOR COMPLETE - OX-1-6S-5, OX-1-6S-8