



PARMCO

OX7-3-6S-5

If PART Number has N/A then Parmco is unable to supply.

Diag #	PART Number	DESCRIPTION
1	N/A - 0040801711	Frame of tube (painted matt black)
2	XXO0040101558	HINGE GUIDE - PYRO-2 VERSO 1-1 OX7-2 OX7-3 OX7-4 OX7-5
3	XXO0040101503	WIRE RACK - VERSO 1-1, OX7-2 OX7-3 OX7-4 OX7-5
4	XXO0040101502	GRILL RACK - VERSO 1-1, OX7-2 OX7-3 OX7-4 OX7-5
5	XXO0042100360	Oven Tray - OX7-3 OX7-4 OX7-5
6	XXO0040900484	ELEMENT, UPPER - VERSO 1-1 OX7-2 OX7-3 OX7-4 OX7-5
7	XXO0040101646	Temp Sensor - both ovens - PPOV-6S-DT-3
8	XXO0040900029	LIGHT BULB - VERSO 1-1, OX-1-6S-5 OX7-2 OX7-3 OX7-4 OX7-5 PPOV-6S-SIDE
9	N/A - 0042100030	Isolation of rear fan (enameled black)
10	XXO0040900052	ELEMENT, CIRCULAR - VERSO 1-1, OX-1-6S-5 OX7-2 OX7-3 OX7-4 OX7-5 PPOV-6S-SIDE
11	XXO0040400075	DOOR SEAL - VERSO 1-1 OX7-2 OX7-3 OX7-4 OX7-5
12	N/A - 0040801216	The front support(left) (painted matt black)
13	N/A - 0040801217	The front support(right) (painted matt black)
14	N/A - 0042100081	Tube (Enameled black)
15	N/A - 0040101565	Ventilated plate
16	XXO0040900426	COOLING FAN - VERSO 1-1 OX7-2 OX7-3 OX7-4 OX7-5
17	N/A - 0040101674	Vent hole of oven
18	N/A - 0040101508	Cooling fan under the partition
19	XXO0040900011	OVERHEAT THERM 170 deg - PYRO-2 OX-1-6S-5 VERSO 1-1 OX7-2 OX7-3 OX7-4 OX7-5 PPOV-
20	N/A - 0020101231	Main oven fixer of temperature limiter
21	N/A - 0042300039	Fixer of the fan
22	N/A - 0040802006	Tube attemperator
23	N/A - 0040802123	Rear attemperator
24	XXO0040900467	CIRCULAR FAN MOTOR - PYRO-2 VERSO 1-1 OX7-2 OX7-3 OX7-4 OX7-5
25	XXO0040101010	KNOB - VERSO 1-1 OX7-3 OX7-4 OX7-5 PPOV-6S-SIDE
26	N/A - 0041800236	Glass control panel (stainless steel)
27	N/A - 0040801715	Fixer of Control panel (painted matte black)
28	XXO0040900025	INDICATOR LIGHT - VERSO 1-1, OX-1-6S-5 OX7-2 OX7-3 OX7-4 OX7-5 PPOV-6S-SIDE
29	XXO0040900332	THERMOSTAT - VERSO 1-1, OX-1-6S-5 OX7-2 OX7-3 OX7-4 OX7-5 PPOV-6S-SIDE
30	XXO0040900739	TIMER - OX-1-6-5, OX7-2-6S-5 OX7-3-6S-5 OX7-5-6S-5 OX7-4-6W-5
31	XXO0040900826	6 step Switch - OX7-3-6S-5
32	N/A - 0040101017	The fixer of the rack
33	XXO0041300227	Side rack - Left - OX7-3 OX7-4 OX7-5
34	XXO0041300228	Side rack - Right - OX7-3 OX7-4 OX7-5
35	N/A - 0040900770A	Oven wire
36	N/A - 0040900900	Power wire
37	N/A - 0040200533	Clasping hand
38	N/A - 0040101492	Left side panel of BIL
39	N/A - 0040101493	Right side panel of BIL
40	XXO0040900031	ELEMENT, LOWER - VERSO 1-1, OX-1-6*-*, OX7-2 OX7-3 OX7-4 OX7-5 PPOV-6S-SIDE
41	N/A - 0040101509	Isolation of lower heater
42	N/A - 0020101350	Bottom panel

43	N/A - 0040101491	Top panel of BIL
44	N/A - 0040101592	The back plate
45	N/A - 0040101494	Back cover of BIL
46	XXO0040900027	Terminal Box - OX7-3 OX7-4 OX7-5 PPOV-6S-SIDE
47	N/A - 0040700536	The inside door glass (LOW-E)
48	XXO0041300040	Hinge - OX7-3-6S-5
49	N/A - 0040400078	Support
50	N/A - 0040700346	The middle-layer glass
51	N/A - 0040200384	Upper fixer of the inside door glass (left)
52	N/A - 0040200385	Upper fixer of the inside door glass(right)
53	N/A - 0040200369	Lower fixer of the inside door glass(left)
54	N/A - 0040200370	Lower fixer of the inside door glass(right)
55	N/A - 0040801712	Vent hole of door (painted matt black)
56	N/A - 0041800136	Aluminum strips outside door glass assembly
57	N/A - 0040100631	H8 stainless steel Handle
58	XXO0040802882	Complete door - OX7-3-6S-5 OX7-3-6S-8

·6S-SIDE