

PARMCO

PPOV-6S-SIDE-1

If PART Number has N/A then it is only available as special order

Diag #	PART Number	DESCRIPTION
1	N/A - 0040801634	Frame of tube (painted matt black)
2	XXO0040100821A	Wire rack - PPOV-6S-DT-3
3	XXO0040101423	GRILL RACK - OX-1-6S-5 PPOV-6S-SIDE
4	XXO0042100359	Oven Tray - PPOV-6S-SIDE
5	XXO0040900244	ELEMENT, UPPER - OX-1-6S-8 PPOV-6S-SIDE, PPOV-6S-DT-3
6	XXO0040900029	COMPLETE LIGHT FITTING FS*00**
7	XXO0040101646	Temp Sensor - both ovens - PPOV-6S-DT-3
8	N/A - 0040800027	Isolation of rear fan (enameled black)
9	XXO0040900052	ELEMENT,CIRCULAR - OX ovens, DT ovens, Verso ovens
10	XXO0040400123	Door seal - lower oven - PPOV-6S-DT-3
11	N/A - 0040801629	The front support(left) (painted matt black)
12	N/A - 0040801630	The front support(right) (painted matt black)
13	N/A - 0040101454	support decorative article
14	N/A - 0040801214	Tube (Enameled black)
15	N/A - 0020101346	Rear support
16	N/A - 0040100683	Ventilated plate
17	XXO0040900240	Thermostat 65degC - PPOV-6S-DT-3
18	N/A - 0040100029	Vent hole of oven
19	XXO0040900426	COOLING FAN - VERSO 1-1 OX7-2 OX7-3 OX7-4 OX7-5 FS*00**
20	N/A - 0040102041	Fixer of cooling fan
21	N/A - 0040101593	Fan support
22	XXO0040900011	OVERHEAT THERM 170 deg
23	N/A - 0040100131	Main oven fixer of temperature limiter
24	XXO0040900034	Circulation Fan - PPOV-6S-SIDE
25	N/A - 0040800525	Tube attemperator
26	N/A - 0040801225	Rear attemperator
27	N/A - 0040800624	Fixer of rear fan
28	XXO0040101010	KNOB - VERSO 1-1 OX7-3 OX7-4 OX7-5 PPOV-6S-SIDE
29	N/A - 0040600170	Plastic stopper of switch
30	XXO0041800227	Control Panel - PPOV-6S-SIDE
31	N/A - 0040801218	Fixer of Control panel (painted matte black)
32	XXO0040900025A	Neon light - PPOV-6S-DT-3 FS*00**
33	XXO0040900332	THERMOSTAT - VERSO 1-1, OX-1-6S-5 OX7-2 OX7-3 OX7-4 OX7-5 PPOV-6S-SIDE FS*00**
34	XXO0040900921A	Clock - PPOV-6S-DT-3
35	XXO0040900828	Function Switch
36	XXO0040100805	SIDE RACKS/ Main oven - OX-1-6S-5 PPOV-6S-SIDE, PPOV- DT-3/4
37	N/A - 0040100820	The fixer of the rack
38	N/A - 0020101643	Left side panel

39	N/A - 0020101348	Right side panel
40	N/A - 0040200533	Built-under double oven Side panel hand
41	XXO0040900031	ELEMENT, LOWER FS600**
42	N/A - 0020101216	Isolation of lower heater
43	N/A - 0020101350	Bottom panel
44	N/A - 0020101351	The cover of the control system
45	N/A - 0020101349	Top panel
46	N/A - 0040100280	Back cover
47	XXO0040900027	Terminal Box - OX7-3 OX7-4 OX7-5 PPOV-6S-SIDE FS*00*G
48	N/A - 0040900757A	Oven wire
49	N/A - 0040900900	Power wire
50	XXO0040801656	Complete Door - PPOV-6S-SIDE
51	N/A - 0040801631	H14 stainless steel Handle
52	N/A - 0040801655	Outside door glass assembly
53	N/A - 0040101449	Magnet iron
54	N/A - 0041300036	Magnet
55	N/A - 0040200379	Magnet fixed box
56	N/A - 0040400069	Magnet rubber parts
57	N/A - 0040101451	Handle fixed pieces
58	N/A - 0040801627	Door lining of side door
59	N/A - 0040801659	Inside door glass assembly