

SCHE
SCHE
SCHE
SCHE
HIL
SCER
SCER
SCER
SCER
Lamp
Heat dissipation fan
45℃Temperature adjuster
Light
Lamp
FUSE 250V 15A
Hand socket outlet
Bottom Grill
Back Grill
Thermostat switch
Circulation fan
P2
P1
P3
TIMER
120℃Thermal cut-out
junction box
Top Grill
Lamp
Thermostat switch
120℃Thermal cut-out